



Note: Rp are optional pullup resistors. They are probably not needed as the internal 20k-50k pullups are enabled in the software.
 Important: - my encoders have maximum current of 1mA. If yours are the same then do not install pullups of less than 6k8.

Interface board for eight rotary encoders