



Link A for TrxAVR pot control of brightness (or if TrxAVR PWM input on J2 pin 3)

Link B for PWM (PL5/OC5C) control of brightness from TrxAVRB

Link C for local VR2 control of brightness

Important !!
 R1-R3 - set the max LED current
 For EAW320B-8k3LW use 3x 22R = 7.3R
 - this gives 190mA assuming LED volts = 3.3

TrxAVR display motherboard and button boards.
 Ian Sumner, Chris Stake 19th April 2009 version 3
 19.4.2009 - Modifications after initial construction testing
 21.4.2009 - C13-16 3n3. R28 & 29 150k